

1

Using a sharp blade, cut a 30mm slot, 50mm deep into the wall.

2

Take two Styrowedge halves and join the smooth sides together.

3

Insert the Styrowedge into the slot in the wall.

**4**

Ensure the Styrowedge is flush with the finish of the wall.

5

Place the downpipe and clip in position on the wall. Insert an 8-12 gauge screw into the Styrowedge and tighten into place.

6

Complete for remaining fastenings. NB. Ensure all penetrations are sealed.